

General imsubs

3711/A, GIDC, Phase-IV, Vatva,
Ahmedabad-382445, India
Ph.: 91-79-583 3845 Fax: 91-79-5833846
E mail: gipl@vsnl.com
Web: www.giplindia.com

Catalogue No.(as per Schlafhorst manual)	Description
80-86	Chain Link
80-93	Over Head Cable Chain Link
80-147	CPL Roller
80-235	Chain Link
80-248	Chain
115-12	Suction Beam Rubber Seal
115-24	Butterfly Valve
115-87	Butterfly Valve
116-14	Seal
125-10	Clamp Connector
152-40	Flange Assembly
211-06	Hexagonal Coupling
210-163	Tension Roller
211-07	Coupling Hub
211-61	Omega Coupling
211-62	Coupling Hub
215-93	Tension Roller
216-69	Tension Roller
217-34	Tension Roller
221-39	Tension Roller
226-161	Flange Bearing
231-27	Tension Roller
237-14	Brush Trash Belt
237-52	Spring Basket
239-04	Suction Tube
252-61	Coupling Half (Omega Coupling)
252-62	Coupling Hub
301-12	Bearing Bush
301-27	Seal
301-32	Leaf Spring
301-37	Toggle Joint
301-38	Torsion Spring
301-43	Sealing Plate
302-13	Gear Wheel
302-19	Cap
302-27	Beveled Cone
302-29	Limit Ring
302-30	Coupling Disc
303-04	Torsion Spring
303-22	Rotor Seal
303-27	Plug (SE-7)
303-29	Bearing Disc (SE7, SE8)
303-36	Seal
303-37	Wick(SE-7, SE-8)
303-38	'O' Ring
303-39	Oil Container
303-42	Rotor Seal
303-43	Bearing Disk for Reflector (SE7, SE8)
304-13	Brake Lever (SE7)
304-17	Brake Shoe (SE7, SE8)
304-22	Press Roller (Without Bearing)
304-52	Supporting Disc (With Bearing)
310-11	Rotor Chamber (SE-7)
310-29	Gasket

310-30	Seal Bush(SE-7)
310-33	Seal Bush (SE-7, SE-8)
310-48	Latch Lever
310-49	Brake Lever
310-51	Latch Spring
310-52	Rotor Chamber (SE-8)
311-04	Slider
311-10	Seal
311-11	Leaf Spring
311-15	Feed Tray
311-19	Condenser Leaf Spring
311-28	Opening Roller Leaf Spring
311-47	Adapter
311-49	Adjusting Piece
311-50	Loading Spring
311-52	Cover Plate Plastic
311-58	Clamp Ring
311-67	Guide Plate
311-68	Condenser Adapter (Green, Brown, Yellow color)
311-76	Clutch Worm Gear
311-77	Magnetic Disk
311-82	Locking Lid
311-83	Coupling Sleeve
311-84	Top Ring
311-88	Seal
312-07	Eccentric (SE7)
312-11	CPL Depressor Roller (Top)
312-12	CPL Depressor Roller(Bottom)
312-15	Double Lock Collar (SE-7, SE-8)
312-16	Eccentric Bolt
312-19	Pull Rod (SE7)
312-25	Latch Lever (SE7, SE8)
312-28	Brake Lever (SE7, SE8)
312-29	Latch Spring
312-36	Adjusting Plate
400-04	Bearing Flange
410-02	Bolt
410-04	Bearing Bolt
410-06	Bearing Bolt
410-08	Bearing Bolt
411-04	Knurled Screw
412-26	CPL Package Cradle (SE-7, SE-8)
414-02	Adapter Hub & Bearing
414-03	Adapter Mount
414-04	Snap On Collar
414-06	CPL Adapter
414-07	Adapter Hub & Bearing
414-08	Adapter Mount
414-10	CPL Adapter
414-11	Adapter Hub & Bearing
414-12	Adapter Mount
414-21	Grooved Ball Bearing
416-09	CPL Relief Rod
416-11	Washer
416-12	Pressure Spring
416-13	Toggle Block

General imsubs

3711/A, GIDC, Phase-IV, Vatva,
Ahmedabad-382445, India
Ph.: 91-79-583 3845 Fax: 91-79-5833846
E mail: gipl@vsnl.com
Web: www.giplindia.com

416-15	CPL Rod
416-25	Gear Wheel
416-27	CPL Angle
416-32	Clamping Plate
420-01	Cam Gear (Single Cam, Double Cam)
420-03	Cam Roller
420-04	Cam Follower
420-08	Support Angle
420-14	Wedge Plate
420-19	Latch
420-20	Bush
420-22	Bearing Pivot
420-35	Eccentric
420-38	Roller
420-41	Torsion Spring
421-42	Drive Belt
426-04	Pressure Rod CPL
426-06	Ball Cup
426-19	Draw Spring
426-23	CPL Pawl Control Lever
426-40	Pressure Rod CPL
426-41	Call Start Button
430-01	CPL Supporting Lever
430-04	CPL Starting Lever
430-12	Rod
430-13	Call Start Button
430-20	Ball Cup
430-21	Pressure Spring
430-22	Washer
430-25	CPL Retraction Lever
430-26	Torsion Spring
430-30	CPL Roller
430-31	CPL Guide Lever
430-32	Eccentric Bolt
430-37	Torsion Spring
430-38	CPL Latch
430-39	Roller
430-41	Pivot Ball
430-46	Contact Cap
430-47	Pull Rod
430-48	Lifter Bail Button (Center Button)
430-50	Ball Cup
430-52	Feeler Wire
430-53	Ball Cup
430-55	CPL Pivoting Sleeve
430-56	Pressure Spring
430-57	Rod
430-58	Lifting Button
430-59	Pressure Spring
430-60	Rod
430-61	Ball Cup
441-23	Clamping Keys
442-20	Pull Rod
442-22	Ball Joint
460-02	Housing
460-05	Flange Bearing
460-19	Latch
460-32	Yarn Support Bail

460-33	Lifter Bail
460-34	Limiting Plate
460-38	CPL Lever
460-41	Pressure Lever
460-45	Stripping Roller
460-46	CPL Cap
460-47	Bolt
462-05	Bail Strut
462-07	Compensating Bow
462-13	Limit Plate
462-15	Support
465-02	Take up Button
465-03	Pressure Spring
465-05	Ball Cup
465-07	Lever
465-11	Stripping Roller
465-15	Pressure Roll Arm
465-16	Cap
465-20	Bolt
465-28	Rubber Ring
466-01	Tread Rod
466-02	Center Button
466-03	Locking Sleeve
466-04	Spring
466-06	Ball Joint
466-13	Lifter Bail
470-05	Drum Sleeve
470-06	Bearing Cover(R.H.)
470-07	Center Bearing Cover
470-08	Bearing Cover (LH)
470-09	Felt Ring
470-20	Main Drive Cylinder
472-05	CPL Yarn Guide
472-12	Clamping Piece
473-02	CPL Displacement Plate
473-05	Sliding Plate
473-09	Thread Guide Eyelet
476-09	Switch Piece
476-15	Push Button
476-16	Pressure Spring
476-22	Bearing Shaft
476-23	Pulse Lever
476-33	Cap
610-24	Blast Pipe
613-36	Sliding Ring
614-12	Displacement Ring
614-26	Brush
614-34	Bearing Bolt
614-35	Bearing Bolt
614-39	CPL Gear Wheel
614-43	Pinion
614-54	CPL Gear Wheel
614-58	Roller
614-68	Wheel Hub
614-78	Ring
614-81	Bracket
615-22	Displacement Ring
615-37	Roller
615-47	Bracket
615-55	Wheel Hub

General imsubs

3711/A, GIDC, Phase-IV, Vatva,
Ahmedabad-382445, India
Ph.: 91-79-583 3845 Fax: 91-79-5833846
E mail: gipl@vsnl.com
Web: www.giplindia.com

615-56	Ring
616-07	Ring
617-06	Latch Lever
617-10	Pressure Spring
617-12	CPL Extension
617-13	Buffer
617-28	Angle Plate
617-46	Switch Angle
617-48	Roller
617-63	Spring Hook
618-11	Latch Plate
619-06	CPL Hook Plate
635-37	Tension Lever
635-38	Press Roller
635-44	Spring Hook
635-72	Bearing Bush
637-07	Cam
637-08	Cam
637-09	Cam
637-10	Cam
637-11	Cam
637-12	Cam
637-13	Cam
637-14	Cam
637-15	Cam
637-18	Cam
637-20	Cam
637-21	Cam
637-22	Cam
637-23	Cam
637-27	Cam
637-28	Cam
638-54	Pressure Lever
639-02	Clamping Lever
640-24	Tooth Segment Lever
640-31	Insertion Wire
641-48	Roller Housing
641-50	Pin
641-54	Gear Wheel
641-61	Roller
641-65	Conical Bush
641-66	Toggle Rod
641-68	Draw Spring
641-69	Stud
641-71	Roller
641-74	Bearing Bolt
641-75	Gear Wheel
641-77	Eccentric Bolt
641-85	Yarn Guide Plate
641-94	Hinged Bolt
641-129	Lifting Wire
641-138	Guide Lever
641-143	Slit Nut
641-145	Segment Lever
641-146	Slit Nut (LH Thread)
641-149	Yarn Guide Plate
645-11	Lever
645-17	Toothed Segments
646-28	Drive Pulley
648-12	Cam Follower

648-74	Feed Sleeve
651-27	Support Wire
658-39	Tension Roller
659-37	Feeder Roller
659-52	Eccentric Bolt
660-03	CPL Switch Roll
662-56	Yarn Guide Plate
672-07	Cam
672-08	Cam
672-09	Cam
672-10 & 672-18	Cam
672-12	Cam
672-13	Cam
674-25	Pressure Lever
674-27	Guide Piece
674-58	Guide Piece
675-01	Control Lever
676-01	Control Lever
676-28	Guide Lever
676-32	Release Lever
676-34	Guide Lever
677-13	Toothed Segments
677-41	Opener Arm
677-46	Adjusting Plate
678-01	Control Lever
679-01	Advance Lever
679-12	Toothed Segments
681-10	Bearing Bolt
681-11	Bearing Bolt
681-13	Guide Tube
681-14	Bolt
681-19	Gear Wheel
681-20	CPL Gear Wheel
681-24	Gear Wheel
681-28	Gear Wheel
681-50	Pinion Shaft
681-53	Drive Cone
681-75	Scrapper (straight & Modified)
681-76	`O' Ring
681-108	Brush
681-211	Stop Plate
681-220	Spacer Piece
681-356	Filling Brush
715-18	Limiting Plate
752-01	CPL Base Flange (RH)
752-04	CPL Base Flange (LH)
752-11	CPL Base Flange (LH)
752-14	CPL Base Flange (RH)
801-75	Bearing Bolt
802-41	Scissors Actuating Lever
802-42	Scissors Actuating Lever
813-48	Bearing Bolt
813-56	Roller Bush
813-58	Roller
813-65	Roller
813-141	Roller
813-146	Covering Disk
813-197	Roller
814-33	Hub

General imsubs

3711/A, GIDC, Phase-IV, Vatva,
Ahmedabad-382445, India
Ph.: 91-79-583 3845 Fax: 91-79-5833846
E mail: gipl@vsnl.com
Web: www.giplindia.com

814-39	Covering Disk
814-42	Roller
814-55	Roller
820-16	Carbon Brush Holder
820-17	Carbon Brush
850-06	Roller
850-31	Bearing Bolt
850-34	Bush
850-35	Roller
850-36	Covering Disk
850-41	Roller
850-43	Roller
851-10	Covering Disk
851-29	Roller
851-31	Roller
851-48	Wheel Hub
	Widen Cleaning
	Articulation Rod Head (LH, 5 mm)
	Articulation Rod Head (RH, 5 mm)
	Articulation Rod Head (LH, 6 mm)
	Articulation Rod Head (RH, 5 mm)
	Articulation Rod Head (LH, 6 mm)With Hex. Nut
	Articulation Rod Head (RH, 6 mm)With Hex. Nut