

	CAT NO SE8	CAT NO.SE9	CAT NO.SE9	DESCRIPTION
1	80-56			CABLE CARRIAGE
2	80-147			CPL ROLLER
3	80-148			BUSH
4	80-227			GROOVED BEARING
5				TIGHTENING ELEMENT 19X24
6				25X30
7				30X35
8				35X40
9		13-6005	117006865	RING
10	115-12	20-22051	117026037	SEAL HOSE
11	115-24	21-22051	117002033	BUTTER FLY VALVE
12	115-70			ANGLE
13	115-87	24-22051	117016699	BUTTER FLY VALVE
14	125-10	18-23551	117021575	CLAMP CONNECTOR
15	125-11			SPACER BUSH
16	125-12			HEX HEAD SCREW
17	14-58			STRAP
18	14-59			LANCE HEAD SCREW
19	14-60			WASHER
20	14-61			LOCKING BOLT
21	14-62			WASHER
22	14-63			SPRING CLAMP
23	14-64			PRESSURE SPRING
24	14-65			E- RING
25	14-66			STRAP
26	14-67			SCREW
27	161-01			FAN UNIT
28	161-2			BLOWER SHAFT
29	161-40			WASHER
30	161-41			SLEEVE DISC
31	161-42			NUT
32	161-43			CPL FAN WHEEL
33	211-06			RUBBER WASHER
34	211-07			COUPLING HUB
35	211-61	17-51058		COUPLING HALF
36	211-62	18-51058	117017667	COUPLING HUB
37	211-67	19-51058	117017668	SPRING COLLAR
38	237-68			ROUND CORD BELT
39	237-73			BRUSH
40	238-63			ROUND CORD BELT
41	239-01			STUD
42	239-4			SUCTION TUBE
43	301-43			SEALING PLATE
44	301-27			SEAL RING
45		198-90091	117441059	SEAL RING
46		11-10025	117001345	TORSION SPRING
47	301-37			TOGGLE JOINT
48	301-38			TORSION SPRING
49	301-55			SWIVEL BOLT L.H.
50	301-57			SWIVEL BOLT RH
51	301-58			BEARING BUSH
52	301-74			LOCK ROLLER

53	302-13	155-90091	117430802	CLUTCH WORM GEAR
54	302-13	155-90091	117430802	GEAR WHEEL
55	302-19	156-90091	11739041	LOCKING LID
56	302-19	156-90091	117411986	CAP
57	302-27	152-90091	117423024	COUPLING SLEEVE
58	302-27	152-90091	117423024	BEVELLED CONE
59	302-29	151-90091	117446213	STOP RING
60	302-29	81-90091	117446213	LIMIT RING
61		154-90091	117441263	MAGNETIC DISC
62	302-30	154-90091	117441263	COUPLING DISC
63	303-04			TOR SPRING
64	303-18	105-90091	905401016	STEEL BALL
65	303-18	105-90091	905401016	STEEL BALL
66	303-29			BEARING DISC
67	303-36			SEAL
68	303-37	119-90091	117462563	WICK
69	303-37	119-90091	117462593	WICK
70	303-38			O RING
71	303-39			OIL CONTAINER
72	303-42			ROTOR SEAL
73	303-43			BEARING DISC, REFLECTOR
74	304-12			SPACER TUBE
75	304-13			BRAKE LEVER
76	304-14			LEG SPRING
77	304-17			BRAKE SHOE SE7, SE8
78	304-22	415-90091	117438269	TENSION ROLLER
79	304-22	415-90091	117438269	PRESSURE ROLLER
80	304-27			BOLT
81	304-30			LOCKING LEVER
82	304-31			BRAKE BOW
83	304-32			GUIDE BUSH
84	304-34			LEAF SPRING
85	304-37			WASHER
86	304-49			COLLAR BUSH
87	304-58			ADJUSTING LEVER
88	303-10			COUPLING
89	303-15			COUPLING
90	306-12			COUPLING
91	310-29	81-90091	117430738	SEAL RING
92	310-33			SEAL BUSH
93	310-45			BOLT
94	310-46			BEARING BUSH
95	310-47			SPACER
96	310-48			LATCH LEVER
97	310-49			BRAKE LEVER
98	310-51			LATCH SPRING
99	310-52	80-90091	117453449	ROTOR CHAMBER. SE8/SE9
100	311-10	331-90091	117426756	SEAL
101	311-11			LEAF SPRING
102	311-12	187-90091	117442277	CONDENSER
103	311-19			CONDENSER LEAF SPRING

104	311-28			OPENING R. LEAF SPRING
105	311-49			ADJUTING PIECE
106	311-50			LOADING SPRING
107	311-52			COVER PLATE
108	311-67			GUIDE PLATE
109	312-04			LATCH LEVER
110	312-05			BRAKE LEVER
111	312-07			ECCENTRIC
112	312-15			DOUBLE LOCK COLLAR
113	312-16			ECCENTRIC BOLT
114	312-25			LATCH LEVER
115	312-27			SPACER
116	312-28			BRAKE LEVER
117	312-29			LATCH SPRING
118	312-30			BOLT
119	312-34			BUSH
120	400-08	11-13001	117000876	TOOTHED WHEEL
121	400-09	12-13001	901472056	DOWEL PIN
122	400-12	15-13001	117014406	COUPLING HALF
123	411-04	5-10090	117004517	KNURLED SCREW
124	411-09	16-10090	117004517	KNURLED SCREW
125	411-21	22-12022	117027496	COVERING HOOD
126	411-21	22-12022	117027496	COVER
127	411-22	10-12022	117023462	COVERING HOOD
128	411-26	15-12022	117028403	HEXAGONAL BOLT
129	411-29	30-12022	117017379	BRACKET
130	411-32	32-12022	117031091	COVERING HOOD
131	414-01	75-14001	117021662	CPL ADAPTER SRZ
132	414-03			ADAPTER MOUNT
133	414-04	85-14001	117019843	CARRIER BUSH
134	414-04	84-14001	117019843	SNAP ON COLLAR
135	414-06			CPL ADAPTER
136	414-07			ADAPTER HUB WITH BRG
137	414-08			ADAPTER MOUNT
138	414-11			ADAPTER HUB WITH BRG SRK
139	414-12			ADAPTER MOUNT
140	414-21	70-14001	117001878	GROOVED BEARING
141	414-22			ADAPTERHUB WITHOUT BRG SRK
142	414-23	68-14001	117016061	ADAPTER
143	414-23	68-14001	117016061	ADAPTER SRK
144	416-15	66-10051	117022254	ROD
145	416-25	71-10051	117014540	TOOTHED WHEEL
146	416-27			CPL ANGLE
147	416-29			SUPPORTING BOLT
148	416-30	93-10051	117001260	PRESSURE SPRING
149	416-32	95-10051	117017095	CLAMPING PLATE
150	416-33	96-10051	117013598	BUSH
151	420-03	73-10051	117011297	CAM ROLLER
152	420-04	75-10051	117029815	GUIDE LEVER
153	420-08			SUPPORT ANGLE
154	420-09			WASHER

155	420-19	100-10051	117015642	LATCH
156	420-22	107-10051	117013264	PIVOT BALL
157	420-35	81-10051	117011248	ECCENTRIC STUD
158	420-38	104-10051	117014578	ROLLER
159	420-41	99-10051	117014756	TORSION SPRING
160	425-01	1-10025	117010876	TORSION SPRING
161	425-05			TORSION SPRING
162	425-17	14-10025	117008582	TORSION SPRING
163	425-19			SLIDE LEVER
164	426-04	156-10051	117030459	PRESSURE ROD
165	426-06	159-10051	836266002	BALL SOCKET
166	426-17	150-10051	117004524	SPRING BASKET
167	426-19	152-10051	117015171	DRAW SPRING
168	426-20	136-10051	117018492	CALL LEVER
169	426-21	147-10051	117023442	KNOCK OFF LEVER
170	426-23	25-10093	117024736	LATCH LEVER
171	426-35	141-10051	117029970	SUPPORTING LEVER
172	426-36	144-10051	117012913	TORSION SPRING
173	426-40	157-10051	117030460	PRESSURE ROD
174	426-41	158-10051	117023812	CALL BUTTON
175	430-01	112-10051	117018490	SUPPORTING LEVER
176	430-04	120-10051	117023210	SWITCH LEVER
177	430-12	2-10085	117001299	ROD
178	430-13	3-10085	117025537	CALL BUTTON
179	430-20	6-10085	836266002	BALL SOCKET
180	430-21	7-10085		PRESSURE SPRING
181	430-22			WASHER
182	430-23			TORSION SPRING
183	430-24	8-10085	117018031	WASHER
184	430-25	127-10051	117023441	RETRACTION LEVER
185	430-26	130-10051	117013346	TORSION SPRING
186	430-41			PIVOT BOLT
187	430-46	4-10085	117003649	CAP
188	430-47	26-10085	117017503	ROD
189	430-48			LIFTER BAIL BUTTON
190	430-50			BALL CUP
191	430-52	15-10085	117013314	FEELER WIRE
192	430-53	16-10085	117019786	BALL SOCKET
193	430-54	17-10085	900934003	HEX NUT
194	430-55			PIVOT SLEEVE
195	430-56			PRESSURE SPRING
196	430-58	27-10085	117019785	LIFT BUTTON
197	430-59	28-10085	117021441	PRESSURE SPRING
198	430-60	29-10085	900433005	WASHER
199	430-61	30-10085	836266002	BALL SOCKET
200	441-25			CONNECTING STUD
201	460-02			HOUSING
202	460-05	37-10065	117029317	FLANGE BEARING
203	460-19			LATCH
204	460-38	15-10065	117016898	LEVER
205	460-41	25-10065	117024737	PRESSURE LEVER

206	460-46	75-10065	117003693	CAP
207	460-47			BOLT
208	462-13			LIMIT PLATE
209	462-15			SUPPORT
210	465-03			PRESSURE SPRING
211	465-04			WASHER
212	465-11	73-10065	117022232	TAKE UP ROLLER
213	465-20			BOLT
214	465-28			RUBBER RING
215	466-01			THREAD ROD
216	466-02			CENTRE BUTTON
217	466-04			LOCKING SLEEVE
218	466-05			WASHER
219	466-06			BALL JOINT
220	466-13			LIFTER BAIL
221	470-012			COUPLING HALF
222	470-05			DRUM SLEEVE
223	470-19	22-12051	117009685	POT
224	470-20	21-12051	117023816	DRIVE ROLLER
225	472-04			THREADED COUPLING
226	472-05	9-12069	117009904	YARN GUIDE
227	472-06	12-12069	117006919	CLAMP
228	472-07	13-12069	900912118	CY. SCREW
229	472-12	27-12069	117018436	CLAMPING PIECE
230	473-02			CPL DISPLACEMENT PLATE
231	473-05			SLIDING PLATE
232	473-09			THREAD GUIDE EYELET
233	476-06			CPL ELECTRONIC STOP MOTION
234	476-15	65-10075	117020888	PUSH BUTTON
235	476-16	66-10075	117020997	PRESSURE SPRING
236	476-22			BEARING SHAFT
237	476-23			PULSE LEVER
238	476-32	64-10075	949846002	
239	476-33	67-10075	117018480	SLIDER
240	610-24	65-6002	117019414	BLOW PIPE
241	613-16	1-60036	117015678	JOINT TUBE
242	613-33	3-60036	117005323	PRESSURE SPRING
243	613-34	4-60036	117005258	COLLAR BUSH
244	613-36	5-60030	117017216	SLIDE RING
245	614-12	36-60010	117005158	DISPLACEMENT RING
246	614-26			BRUSH
247	614-33	98-60010	117005487	MOTOR PINION
248	614-34	4-60010	117002323	BEARING BOLT
249	614-35	5-60010	117011039	BEARING BOLT
250	614-39	13-60010	117002324	TOOTHED WHEEL
251	614-43	19-60010	117005011	WHEEL HUB
252	614-54	99-60010	117005488	TOOTHED WHEEL
253	614-56			BEARING BOLT
254	614-58	50-60010	117009122	ROLLER
255	614-68	23-60010	117019782	PINION
256	614-71			RING

257	614-81	64-60010	117022429	THRUST ROLLER BRACKET
258	615-05			BRUSH
259	615-08	12-60015	117022429	THRUST ROLLER BRACKET
260	615-22	44-60015	117005158	DISPLACEMENT RING
261	615-37			ROLLER
262	615-47	12-60015	117022429	THRUST ROLLER BRACKET
263	615-55	43-60015	117019783	WHEEL HUB
264	616-01			SUPPORTING ARM
265	616-07			RING
266	617-06	16-60025	117006815	LATCH NOSE
267	617-10	26-60025	117016754	PRESSURE SPRING
268	617-12	32-60025	117013200	EXTENSION
269	617-13	37-60025	836240001	BUFFER
270	617-31	62-60025	117006248	DRAW SPRING
271	617-45			TOR SPRING
272	617-46			SWITCH ANGLE
273	617-48			ROLLER
274	617-50			TOR SPRING
275	618-11	16-60030	117023332	LATCH
276	618-13	34-60030	117005195	TORSION SPRING
277	619-06	17-60045	117012983	HOOK PLATE
278	619-07	21-60045	117029391	ELBOW
279	619-09	22-60045	117016356	BOLT
280	619-11	28-60045	117007643	TORSION SPRING
281	619-18	44-60045	117013534	PRESSURE SPRING
282	635-38	46-62101	117007013	TENSION ROLLER
283	635-38			TENSION LEVER
284	637-01			SHAFT
285	637-06			FITTING KEY
286	637-07			CAM
287	637-08			CAM
288	637-09			CAM
289	637-10			CAM
290	637-11			CAM
291	637-12			CAM
292	637-13			CAM
293	637-14			CAM
294	637-15			CAM
295	637-18			CAM
296	637-20			CAM
297	637-21			CAM
298	637-22			CAM
299	637-23			CAM
300	637-25			LOCK WASHER
301	637-26			GROOVED NUT
302	637-27			CAM
303	637-28			CAM
304	637-38			CAM
305	638-08	15-62018	117005699	HELICAL WHEEL
306	638-16	31-62018	117005702	HELICAL WHEEL
307	638-54			PRESSURE LEVER

308	638-64			TOR SPRING
309	640-08	11-62022	117008672	SPRING HOOK
310	640-08	08-62123	117005445	SPRING HOOK
311	640-18			YARN LIFT SHAFT
312	640-24	1-62022	117012338	SEGMENT LEVER
313		32-62022	117022243	INSERTION WIRE
314	640-25	40-62022	117008671	BEARING BUSH
315	640-31			INSERTION WIRE
316	641-08			IMTERMEDIATE WHEEL
317	641-10	10-62123	117005809	INTERMEDIATE WHEEL
318	641-124			BRACKET
319	641-128			LEVER PLATE
320	641-129			LIFTING WIRE
321	641-138			GUID E LEVER
322	641-14	20-62123	117007579	INTERMEDIATE WHHEL
323	641-140	103-62123	117007363	WASHER
324	641-141	105-62123	117007364	WASHER
325	641-143	108-62123	117006617	SLOTTED NUT
326	641-145	01-62123	117012339	SEGMENT LEVER
327	641-146	122-62123	117007362	SLOTTED NUT
328	641-149			YARN GUIDE PLATE
329	641-15	21-62123	117007580	INTERMEDIATE WHEEL
330	641-20	157-62123	117009526	CPL DRAW SPRING
331	641-48			ROLLER HOUSING
332	641-54			GEAR WHEEL
333	641-61	104-62123	117007357	ROLLER
334	641-62	106-62123		CAGE
335	641-62	117-62123	832656013	CAGE
336	641-65	109-62123	117005031	CONICAL BUSH
337	641-65	123-62123	117005031	CONICAL BUSH
338	641-66	110-62123	117026584	TOGGLE ROD
339	641-68	111-62123-	117005042	STUD
340	641-74	125-62123	117026604	BEARING BOLT
341	641-77	129-62123	117023648	ECCENTRIC STUD
342	641-82	137-62123	117021168	YARN GUIDE PLATE
343	641-84	139-62123	117009435	LIMIT STOP
344	641-85	145-62123	117023189	YARN GUIDE PLATE
345	641-94	98-62123	117023682	HINGE BOLT
346	642-15			CPL DRAW SPRING
347	642-16	06-62085	117014021	PRESSURE LEVER
348	642-20	16-62085	117005562	LIMIT STOP
349	643-04			PULL ROD
350	644-12			PRESSURE LEVER
351	644-15			LIMIT STOP
352	645-11	24-62027	117006215	LEVER
353	645-16	49-62027	117009543	CPL DRAW SPRING
354	645-17	52-62027	117006216	TOOTHED SEGMENT
355	645-33	61-62027	11706234	INSERTION WIRE
356	646-28	120-62078	117027172	DRIVE PULLEY
357	646-53			PULL ROD
358	646-60			CPL DRAW SPRING

359	647-27			GEAR WHEEL
360	647-36	109-62079	117005415	BUSH
361	647-74	110-62079	117005474	FEED SLEEVE
362	647-75	76-62079	901481021	DOWEL PIN
363	648-1	1-62030	117020394	FLANGE
364	648-12	25-62030	117016038	CAM FOLLOWER
365	648-15	34-62030	117005944	PULL ROD
366	648-21	42-62030	117008188	DRAW SPRING
367	651-27	69-62033	117021615	SUPPORT WIRE
368	651-32	78-62033	117008674	DRAW SPRING
369	656-1	2-62038	117007101	GOVERNOR

370	656-7	10-62038	117006248	DRAW SPRING
371	659-30			BEARING PLATE
372	659-36	56-62070	117024545	FEEDER ARM
373	659-37	7-62070	117016040	FEEDER ROLLER
374	659-52	53-62070	117014519	ECCENTRIC BOLT
375	660-20	6-62055	117007572	CAP
376	660-20			PUSHER CAP
377	660-21	7-62055	117007570	PRESSURE SPRING
378	660-21			PRESSURE SPRING
379	660-3	5-62055	117021062	CPL SWITCH ROD
380	660-3	5-62551	117019742	BEARING SHAFT
381	662-36	66-62551	117005135	PULL ROD
382	662-40	73-62551	836269020	UNIVERSAL JOINT
383	662-41	72-62551	836269009	UNIVERSAL JOINT
384	662-54	15-62551	117012404	SHAFT
385	662-56	22-62551	117019809	YARN GUIDE PLATE
386	662-63	66-62551	117005435	PULL ROD
387	663-27	17-62520	117013842	NOZZLE
388	664-26	3-62545	117021404	TORSION SPRING
389	664-66			CPL SCISSOR
390	672-10	15-64010	117015536	CAM
391	672-11	27-64010	117015565	CAM
392	672-12	31-64010	117016490	CAM
393	672-13	35-64010	117020860	CAM
394	672-18	24-64010	117011018	CAM
395	672-7	7-64010	117014997	CAM
396	672-8	10-64010	117026388	CAM
397	672-9			CAM
398	674-25	22-64020	117005133	PRESSURE LEVER
399	674-27	24-64020	117013463	GUIDE PIECE
400	674-31			TOR.SPRING
401	674-58			GUIDE PIECE
402	675-1	1-64020	117013227	CONTROL LEVER
403	675-5	14-64020	117008672	SPRING HOOK
404	675-8	11-64020	117009545	DRAW SPRING
405	676-28	69-64025	117011303	GUIDER LEVER
406	676-32			RELEASE LEVER
407	676-34	80-64025	117026185	GUIDE LEVER
408	676-37	88-64025		BREAK PLATE
409	676-38	91-64025		ROLLER
410	677-1	1-64030	117017443	CONTROL LEVER
411	677-11	121-64030	117013195	TORSION SPRING
412	677-12	22-64030	117016059	OPENER ARM
413	677-13	34-64030	117013218	TOOTHED SEGMENT
414	677-25	13-64030	117005281	PULL ROD
415		96-64030	117011948	CONTROL LEVER
416	677-29	61-64030	117022584	CPL DRAW SPRING
417	677-36	39-64030	117029498	ROCKER LEVER
418	677-41	81-64030	117021587	OPENER ARM
419	677-43	93-64030	117014673	TORSION SPRING
420	677-46	101-64030	117011932	ADJUSTING PLATE

421	677-5	10-64030	117016447	CLAMPING LEVER
422	677-59	86-64030	117012469	STOP PIN
423	677-60	87-64030	117012470	ROLLER
424	677-82	17-64030	836269009	UNIVERSAL JOINT
425	677-84	18-64030	836269020	UNIVERSAL JOINT
426	678-12	26-64030		PULL ROD
427	678-13	30-64030		UNIVERSAL JOINT
428	678-14	31-64030	836269020	UNIVERSAL JOINT
429	679-04	7-64045	117005435	PULL ROD
430	679-1	1-64040	117013200	ADVANCE LEVER
431	679-12	17-64040	117029864	TOOTHED SEGMENT
432	679-20	14-64040	117017114	CPL DRAW SPRING
433	679-32	11-64045	836269020	UNIVERSAL JOINT
434	679-4			PULL ROD
435	680-1	1-64045	117013201	ROCKER LEVER
436	680-4	7-64045	117005435	PULL ROD
437	681-10	138-64050	117022855	BEARING BOLT
438	681-108	16-64050	117030205	BRUSH
439	681-11	138-64050		BEARING BOLT
440	681-13			GUIDE TUBE
441	681-14			BOLT
442	681-19	107-64050	117029587	GEAR WHEEL
443	681-20	110-64050	117005854	CPL GEAR WHEEL
444	681-211	139-64050	117023068	STOP PLATE
445	681-22	116-64050	117005853	GEAR WHEEL
446	681-28	91-64050	117005859	GEAR WHEEL
447	681-298	187-64050	117017121	CPL LEVER
448	681-356	242-64050	117018057	CLEANING BRUSH
449	681-49	36-64050	117005860	GEAR WHEEL
450	681-50	45-64050	117016541	PINION SHAFT
451	681-53	47-64050	117032378	INTERMEDIATE PIECE
452	681-75	195-64050	117454221	SCRAPPER
453	681-76	48-64050	836460148	O' RING
454	715-18			LIMITING PLATE
455	750-6	20-71525	117004283	CPL STOP BOLT
456	750-8	25-71525	117000542	BEARING SCREW
457	752-1			BASE FLANGE RH
458	752-10	3-71567	117001878	SELF ALIGNING BALL BEARING
459	752-11	47-71567	117029130	BASE FLANGE LH
460	752-12	48-71567	117013124	ADAPTOR PLATE LH
461	752-14			BASE FLANGE RH
462	752-15			ADAPTOR PLATE RH
463	752-3			ADJUSTING PLATE
464	752-4	48-71567	117013124	BASE FLANGE LH
465	752-9	1-71567	117016112	CARRIER BUSH
466	756-56	25-71529	117012946	BEARING BOLT
467	756-58	27-71529	117012345	CLAMPING PLATE
468	756-59	28-71529	117021242	PIVOTING SHEARING BLADE
469	756-60	29-71529	117021241	STATIONARY SHEARING BLADE
470	756-61	30-71529	117021316	CLAIMPING PLATE
471	756-62	34-71529	117013144	CLAIMPING PLATE

472	756-63	35-71529	117011266	LEAF SPRING
473	756-64	36-71529	117011267	PRESSURE SPRING
474	760-25	28-71517	117007446	DRAW SPRING
475	770-39			PRESSURE SPRING
476	775-10	63-72501	117001521	TORSION SPRING
477	775-35	52-72501	117017767	LEVER
478	775-9	62-72501	117001520	SWITCH PAWL
479	80-147	9-24520	117028181	CPL ROLLER
480	80-148	8-24520	117028185	BUSH
481	80-155	16-24520	900931062	HEX HEAD SCREW
482	80-227	17-24501	832697028	GRUD BALL BEARING
483	802-41	21-70055	117016264	SCISSORS ACTUATING LEVER
484	802-42	15-70055	117016259	SCISSORS ACTUATING LEVER
485	80-56	1-24051	117028041	CABLE CARRIAGE
486	813-141	77-71001	117012573	ROLLER
487	813-145	82-71001	117012576	POSITIONING SCREW
488	813-146	74-71001	117015729	COVERING DISC
489	813-197	88-71001	117032195	ROLLER
490	813-48	65-71001	1170113022	BEARING BOLT
491	813-56	70-71001	117012572	ROLLER BUSH
492	813-58	71-71001	117002162	ROLLER
493	813-65	91-71001	117028964	ROLLER
494	813-69	108-71001	117035873	ROLLER BRUSH
495	814-33	5-71006	117019246	HUB
496	814-35	18-71006	117011111	RECHET WHEEL
497	814-39	17-71006	117015729	COVERING DISC
498	814-42	40-71006	117012573	ROLLER
499	814-46	41-71006	117012576	POSITIONING SCREW
500	814-55	42-71006	117032195	ROLLER
501	816-35	56-70022	117017020	BEARING CAM
502	820-12	396-71030	117008307	HOLDING ANGLE
503	820-13	399-71030	117008309	STUD
504	820-14	400-71030	117008328	TORSION SPRING
505	820-16	403-71030	138003832	LEVER
506	820-17	404-71030	107023081	CARBON
507	850-06	14-77001	117016189	ROLLER
508	850-31	29-77001	117013027	BEARING BOLT
509	850-34	33-72501	117012572	BUSH
510	850-35	34-77001	117002162	ROLLER
511	850-36	35-77001	117015729	COVERING DISC
512	850-41	44-7701	117012573	ROLLER
513	850-42	45-77001	117012576	BEARING SCREW
514	850-43	46-77001	117032195	ROLLER
515	851-10	13-77005	117015729	COVERING DISC
516	851-11	14-77005	117011111	RATCHET WHEEL
517	851-29	44-77005	117012573	ROLLER
518	851-30	45-77005	117012576	BEARING SCREW
519	851-31	46-77005	117032195	ROLLER
520	851-33	46-77005	117032195	GROOVED BEARING
521	851-48	9-77005	117019246	WHEEL HUB
522		21-90091	117436208	COMPENSATING WASHER

523		22-90091	117450925	SWIVEL BOLT
524		23-90091	117427751	BEARING BUSH
525		25-90091	117459165	LOCK ROLLER
526		28-90091	836235034	SPRING WASHER
527		84-90091	909021005	WASHER
528		85-90091	117441034	STARTING BUSH
529		111-90091	117441035	SEALING WASHER
530		164-90091	117435486	COVER PLATE
531		176-90091	117438601	TORSION SPRING
532		178-90091	906799002	LOCKING RING
533		315-90091	117448526	SLIDE
534		340-90091	117464135	WALL
535		208-90091	117435488	CLAMP RING
536		103-90091	117445541	SUPPORTING DISC
537		109-90091	117445543	SUPPOIRTING DISC
538		116-90091	117440514	SEAL RING
539		120-90091	117434172	BRAKE SHOE
540		132-90091	117433767	POIL CONTAINER
541		133-90091	117440514	SEAL RING
542		135-90091	117436213	HOOK-UP-PIECE
543		138-90091	117454211	HOOK-UP-PIECE
544		245-90091	117434408	SEAL RING
545		160-10051	900934004	HEX NUT
546		13-10075	117017782	LEVER
547		20-10085	117017772	SLIDER
548		1-12051	117028789	WINDING SHAFT
549		8-12051	117025851	LIFTER BAIL
550		9-12051	117005835	COVER
551		10-12051	117023451	COVER
552		11-12051	117001272	COVER
553		18-12063	117023872	COMPENSATING BOW
554		150-19910	117029587	BELT TENSIONING DEVICE
555		45-19910	860242014	ALLENKEY
556		49-19910	117004770	SOCKET WRENCH
557		10-19910	117440591	WRENCH FOR OIL CONTAINER
558		81-19910	117443648	SPECIAL WRENCH
559		133-19910	117441319	SET PIN
560		137-20051	117527156	DEPRESSER ROLLER
561		12-22051	117024684	ELBOW
562		31-20051	117014236	STRAP
563		20-22051	117026037	SEAL HOSE
564		21-22051	117002033	BUTTERFLY VALVE
565		24-22051	117016699	BUTTERFLY VALVE
566		27-22056	117026027	SEAL HOSE
567		33-22064	117026037	SEAL HOSE
568		40-22082	117026037	SEAL HOSE
569		22-23031	905419002	FELT RING
570		23-23031	905419003	FELT RING
571		18-23551	117021575	CLAMP CONNECTOR
572		14-23557	117021575	CLAMP CONNECTOR
573		1-24501	117028041	CABLE CARRIAGE

574		9-24501	832597028	GROOVED BALL BEARING
575		13-26001	117011713	CHAIN LINK
576		37-26001	117026525	CHAIN LINK
577		38-26001	117026526	CHAIN LINK
578		41-41007	107019957	LOCK PLATE
579		41-41013	107019957	LOCK PLATE
580		35-41037	117010578	SPRING HOOK
581		40-41037	117005146	LATCH
582		41-42062	117015633	CONV.TENSIONING ROLLER
583		99-42062	117015633	CONV.TENSIONING ROLLER
584		...42091		CPL BRUSH TRASH BELT
585		29-43005	117018406	CONV.TENSIONING ROLLER
586		76-43005	117018405	CONV.TENSIONING ROLLER
587		130-50456		CONV.TENSIONING ROLLER
588		17-51058		OMEGA COUPLING
589		18-51058	117017668	COUPLING HUB
590		19-51058	117017668	THRUST COLLAR
591		20-51068	117017666	SPACER RING
592		21-51058	836238010	CLAMP COLLAR
593		33-52154	117018405	CONV.TENSIONING ROLLER
594		49-52154	117018405	CONV.TENSIONING ROLLER
595		18-52354	117018405	CONV.TENSIONING ROLLER
596		97-52355	117018405	CONV.TENSIONING ROLLER
597		55-52359	117015633	CONV.TENSIONING ROLLER
598		54-52552	117015633	CONV.TENSIONING ROLLER
599		54-52555	117015633	CONV.TENSIONING ROLLER
600		35-53031	117018405	CONV.TENSIONING ROLLER
601		10-54052	836238015	CLAMP COLLAR
602		25-6005	117035873	BRUSH
603		23-60015	117009122	ROLLER
604		43-60015	117019783	WHEEL HUB
605		44-60015	117005158	DISPLACEMENT RING
606		45-60015	117019776	RING
607		53-64050	117030574	SPACER BLOCK
608		107-64050	117029587	TOOTHED WHEEL
609		110-64050	117005854	TOOTHED WHEEL
610		130-64050	117022857	STRTCHER PLATE
611		242-64050	117018057	CLEANING BRUSH
612		80-70015	117014935	TORSION SPRING
613		15-70015	117016259	SCISSORS ACTUATING LEVER
614		21-70015	117016264	SCISSORS ACTUATING LEVER
615		65-71001	117013027	BEARING BOLT
616		70-71001	117012572	BUSH
617		71-71001	17002162	BEARING BOLT
618		74-71001	117015729	COVERING DISC
619		77-71001	117012573	ROLLER
620		88-71001	117032195	ROLLER
621		91-71001	117028964	ROLLER
622		5-71006	117019246	WHEEL HUB
623		17-71006	117015729	COVERING DISC
624		40-71006	117012573	ROLLER

625		42-71006	117032195	ROLLER
626		396-71030	117008307	MOUNTING ANGLE
627		400-71030	117008328	TORSION SPRING
628		403-71030		LEVER
629		404-71030	117023081	CARBON
630		4-71050	117028964	ROLLER
631		52-71050	117002162	ROLLER
632		58-71050	117032195	ROLLER
633		59-71050	117012573	ROLLER
634		25-71525	117000542	BEARING SCREW
635		.25-71529	117012946	BEARING BOLT
636		27-71529	117012345	CLAMPING PLATE
637		28-71529	117011242	PIVOTING SHEARING BLADE
638		29-71529	117021241	STATIONARY SHEARING BLADE
639		30-71529	117021316	CLAMPING PLATE
640		34-71529	117012944	CLAMPING PLATE
641		35-71529	117011266	LEAF SPRING
642		36-71529	117011267	PRESSURE SPRING
643		37-71529	90902100	WASHER
644		19-71533	117011750	PULL ROD
645		20-71533	117008612	PULL ROD
646		21-71533	836269009	UNIVERSAL JOINT
647		46-71533	117017736	PULL ROD
648		47-71533	117008611	PULL ROD
649		48-71533	836269009	UNIVERSAL JOINT
650		51-71533	836269020	UNIVERSAL JOINT
651		65-71533	117017621	PULL ROD
652		66-71533	117017622	PULL ROD
653		68-71533	836269024	UNIVERSAL JOINT
654		70-71533	836269023	UNIVERSAL JOINT
655		66-72501	117004857	ROD
656		70-72501	836269009	UNIVERSAL JOINT
657		71-72501	836269020	UNIVERSAL JOINT
658		76-64025	117026186	BREAK LEVER
659		71-72501	836269020	UNIVERSAL JOINT
660		76-64025	117026186	BREAK LEVER